



Supplied

Roller blind system
brackets

Fixing screws

Control chain safety clip



What you'll need

Tape measure

Spirit level

Soft pencil

Screwdriver

Hammer

How to install

Installing your blind is easy. We supply all of the necessary brackets and fixings to install into your wall or window recess.



If you have any questions about installation, please contact us on 0118 922 1327 or email info@surfaceview.co.uk for further information and advice.



Installing Brackets

Positions illustrated are for a blind with the control chain on the right. For a blind with the control chain on the left the bracket should be on the opposite end.

Brackets can be fixed to any flat surface behind or above our blinds.

First mark the location of the brackets and use a spirit level to check they are level. Check that the rolled fabric will not touch any surface and that the blind fabric when unrolled will not foul on any window mechanisms or latches.

Use the appropriate screws and rawlplugs to fix the brackets to your wall.

Installing Blinds

Hold the blind to the brackets with the fabric hanging in front of the blind system.

Fit the spring plunger into its bracket. Push the blind into this bracket, depressing the plunger.

With the locating hook on the opposite end pointing downwards, place the hook into the vertical part of the '+' shaped bracket.

Allow the hook to drop downwards so that it locks into place in the bracket.

Each roller blind is supplied with a control chain safety clip which we recommend be installed with each blind.

If you have any questions about installation, please contact us on 0118 922 1327 for further information and advice